



PARTS:

1. M8 x 30mm SOCKET SCREW (FIG: 5.03)
2. CON-B (NON-THREADED) (FIG: 5.11)
3. CON-A (THREADED) (FIG: 5.12)

WARNING:

- ADD-ON FRAMES MUST BE INSTALLED PRIOR TO CONNECTING THE PANELS TO ANY OTHER COMPONENTS
- IF YOU NEED EXTRA CON-B BRACKETS, THEY ARE LOCATED IN THE HARDWARE PACK