



### PARTS:

1. M8 x 20mm SOCKET SCREW (FIG: 5.02)
2. CON-B (NON-THREADED) (FIG: 5.11)
3. PRE-MOUNTED CON-A (FIG: 5.12)

### WARNING:

- IF YOU HAVE ADD-ON FRAMES, THEY MUST BE INSTALLED PRIOR TO INSTALLING THE PANEL TO THE POSTS
- IF YOU NEED EXTRA CON-B BRACKETS, THEY ARE LOCATED IN THE HARDWARE PACK